

# ESSENTIAL SEASONAL MAINTENANCE SCHEDULE

# SELECTRUCKS®

SPRING	SUMMER	FALL	WINTER
<p><b>TIRES:</b></p> <p>Check tire pressure and tread depth after the colder months. Replace any worn-out tires and ensure proper inflation.</p>	<p><b>FLUIDS:</b></p> <p>Check and top off fluids such as engine oil, coolant, and windshield washer fluid, as hot weather can increase their consumption.</p>	<p><b>BRAKES:</b></p> <p>Check brake pads, drums, and brake fluid levels. Replace worn-out brake components as needed to maintain reliable stopping power.</p>	<p><b>HEATING SYSTEMS:</b></p> <p>Ensure the cab heater and defroster are functioning correctly for the sake of visibility and comfort during cold weather.</p>
<p><b>FILTERS:</b></p> <p>Change your air, fuel, and oil filters for optimal engine performance.</p>	<p><b>CLEAN RADIATOR:</b></p> <p>Keep your radiator clean to prevent overheating. Use a soft brush or compressed air to remove debris.</p>	<p><b>BATTERIES:</b></p> <p>Check the condition of batteries, ensuring they are fully charged and able to handle colder temperatures.</p>	<p><b>TIRES:</b></p> <p>Check tire pressure frequently as cold temperatures can cause pressure to drop. Consider using winter tires for improved traction in snow and ice.</p>
<p><b>COOLING SYSTEMS:</b></p> <p>Inspect hoses, belts, and coolant levels to prevent overheating as temperatures rise.</p>	<p><b>AIR CONDITIONING:</b></p> <p>Test and service your truck's air conditioning system to keep comfortable during hot summer drives.</p>	<p><b>LIGHTS:</b></p> <p>Ensure all lights are working properly as days get shorter. Clean lenses and replace bulbs as needed.</p>	<p><b>PROTECT AGAINST CORROSION:</b></p> <p>Apply rust-proofing treatments to exposed metal parts to protect against salt and road chemicals used for snow and ice removal.</p>